




Stage 1 — Devise a list of equipment that will be required to allow wireless technology to be implemented within the local charity.



Stage 2 — Obtain and setup the wireless equipment, describe/log/picture log/vlog the steps to achieve this build





I changed laptop network card to a wireless one.




I also changed the network card on pc to a wireless one as well.

Stage 3 — Devise and implement a suitable authentication and encryption scheme to allow users to use the wireless network







On router -> GUI -> Wireless -> Wireless security -> changed mode to WPA Personal and added Passphrase -> save settings




Then I went to Tablet-> config->Wireless0-> I changed MAC address, SSID and selected WPA2-PSK and added passphrase




On smartphone -> I repeated the same process -> config->Wireless0-> I changed MAC address, SSID and selected WPA2-PSK and added passphrase




On the PC I also repeated the same steps




On the laptop I went to Desktop -> PC wireless-> Profiles -> Added my EC number as profile name -> clicked Ok




I clicked Advanced Setup -> Added my EC number as Network name > clicked next




Then I selected WPA2-Personal ->Next



Then I added the passphrase key ->Next



Laptop is now connected



I then went back to config ->Wireless0 -> to change the MAC address as shown above

Stage 4 — Implement wireless MAC address filtering to further secure the wireless network

```
Physical Config Desktop Programming Attributes
Packet Tracer PC Command Line 1.0
Bluetooth Connection: (default port)
   nection-specific DNS Suffix..:
 DHCP Servers..... 0.0.0.0
 DNS Servers....:
Wireless0 Connection:
 Default Gateway....:
 DHCP Servers. 192.168.0.1
 0.0.0.0
--More--
```

On PC I went to Desktop -> Command prompt -> typed command ipconfig /all

```
ipconfig /all
Bluetooth Connection: (default port)
  Connection-specific DNS Suffix..:
  IPv4 Address..... 0.0.0.0
  Subnet Mask...
  Default Gateway....::::
  DHCPv6 Client DUID.....: 00-01-00-01-81-48-91-E7-00-0A-00-0A-00-03
  DNS Servers....
                              0.0.0.0
Wireless0 Connection:
  Connection-specific DNS Suffix..:


      IPv4 Address
      : 192.168.0.104

      Subnet Mask
      : 255.255.255.0

  Default Gateway....:::
                              192.168.0.1
  DHCP Servers...... 192.168.0.1
  DHCPv6 [AID.....:
DHCPv6 Client DUID......: 00-01-00-01-81-48-91-E7-00-0A-00-0A-00-03
  DNS Servers....:
```

Then I did the same process for the smartphone (to Desktop -> command prompt -> and typed ipconfig /all command)

On Tablet - Desktop -> command prompt -> and typed ipconfig /all command



Finally, I went to the router ->GUI -> Wireless ->Wireless MAC filter -> I added the MAC addresses of clients to permit wireless network access